



# Zombie Zapper

Part of the Zombie Management System



Power Switch

To use the Zombie Zapper, flip the power switch on. It will go through a brief battery check and show up to 5 green lights indicating it's current power level. If only one blue light is flashing, the battery level is too low and the batteries must be recharged.

To activate the zapper, press the trigger. If the trigger is held down for too long, the Zombie Zapper will flash red and enter a time out mode for 30 seconds. Turning off the Zombie Zapper during this time will reset the timer to 30 seconds.

There are five modes. The modes are indicated when first powered on by a single led starting at the base (mode 1) prior to the White and Green battery check.

To change the Firing Mode, hold the trigger while turning on the unit, release when the LEDs turn green. You will notice the single lit led moves up a ring for each mode.

Trigger

Mode 1-LED lights traces up to arc-reactor.

Arcs spark one at a time in circle pattern.(most energy efficient)

Mode 2-Flashes all LEDs randomly. Arcs spark one at a time randomly.

Mode 3-No LEDs flash, fires all three arcs at the same time.

Mode 4-Flashes all LEDs in random pattern and fires all arcs at the same time. (least energy efficient)

Mode 5-Trickster mode. First press of fire button only

blinks random LEDs (no arcs). Second press fires like mode 4

To recharge the battery, remove the base of the unit, remove the battery and plug the battery into the provided charger then plug the charger into the wall outlet.

When all the lights are blue, charging is complete.

Stand the Zombie Zapper upside down when not in use.

- Do not use if broken
- Do not use in the rain
- Do not let the unit get wet
- Do not put anything between the plastic guards
- Do not operate near flammable substances
- Operate and Store between 20° and 100° F (-6° to 38°C)

Battery Compartment

